

AVRDUDE

A program for download/uploading AVR microcontroller flash and eeprom.
For AVRDUDE, Version 5.10, 2 March 2011.

by Brian S. Dean

Send comments on AVRDUDE to avrdude-dev@nongnu.org.

Use <http://savannah.nongnu.org/bugs/?group=avrdude> to report bugs.

Copyright © 2003,2005 Brian S. Dean

Copyright © 2006 - 2008 Jörg Wunsch

Permission is granted to make and distribute verbatim copies of this manual provided the copyright notice and this permission notice are preserved on all copies.

Permission is granted to copy and distribute modified versions of this manual under the conditions for verbatim copying, provided that the entire resulting derived work is distributed under the terms of a permission notice identical to this one.

Permission is granted to copy and distribute translations of this manual into another language, under the above conditions for modified versions, except that this permission notice may be stated in a translation approved by the Free Software Foundation.

Table of Contents

| | | |
|--------------------------------------------------|-------------------------------------------|-----------|
| 1 | Introduction | 1 |
| 1.1 | History and Credits | 2 |
| 2 | Command Line Options | 3 |
| 2.1 | Option Descriptions | 3 |
| 2.2 | Programmers accepting extended parameters | 13 |
| 2.3 | Example Command Line Invocations | 15 |
| 3 | Terminal Mode Operation | 19 |
| 3.1 | Terminal Mode Commands | 19 |
| 3.2 | Terminal Mode Examples | 20 |
| 4 | Configuration File | 23 |
| 4.1 | AVRDUDE Defaults | 23 |
| 4.2 | Programmer Definitions | 23 |
| 4.3 | Part Definitions | 23 |
| 4.3.1 | Instruction Format | 24 |
| 4.4 | Other Notes | 25 |
| 5 | Programmer Specific Information | 26 |
| 5.1 | Atmel STK600 | 26 |
| Appendix A Platform Dependent Information | | 29 |
| A.1 | Unix | 29 |
| A.1.1 | Unix Installation | 29 |
| A.1.1.1 | FreeBSD Installation | 29 |
| A.1.1.2 | Linux Installation | 29 |
| A.1.2 | Unix Configuration Files | 30 |
| A.1.2.1 | FreeBSD Configuration Files | 30 |
| A.1.2.2 | Linux Configuration Files | 30 |
| A.1.3 | Unix Port Names | 30 |
| A.1.4 | Unix Documentation | 30 |
| A.2 | Windows | 30 |
| A.2.1 | Installation | 30 |
| A.2.2 | Configuration Files | 31 |
| A.2.2.1 | Configuration file names | 31 |
| A.2.2.2 | How AVRDUDE finds the configuration files | 31 |
| A.2.3 | Port Names | 31 |
| A.2.3.1 | Serial Ports | 31 |
| A.2.3.2 | Parallel Ports | 31 |

| | | |
|-------------------|------------------------------|-----------|
| A.2.4 | Using the parallel port..... | 32 |
| A.2.4.1 | Windows NT/2K/XP..... | 32 |
| A.2.4.2 | Windows 95/98..... | 32 |
| A.2.5 | Documentation..... | 32 |
| A.2.6 | Credits..... | 32 |
| Appendix B | Troubleshooting..... | 33 |

1 Introduction

AVRDUDE - AVR Downloader Uploader - is a program for downloading and uploading the on-chip memories of Atmel's AVR microcontrollers. It can program the Flash and EEPROM, and where supported by the serial programming protocol, it can program fuse and lock bits. AVRDUDE also supplies a direct instruction mode allowing one to issue any programming instruction to the AVR chip regardless of whether AVRDUDE implements that specific feature of a particular chip.

AVRDUDE can be used effectively via the command line to read or write all chip memory types (eeprom, flash, fuse bits, lock bits, signature bytes) or via an interactive (terminal) mode. Using AVRDUDE from the command line works well for programming the entire memory of the chip from the contents of a file, while interactive mode is useful for exploring memory contents, modifying individual bytes of eeprom, programming fuse/lock bits, etc.

AVRDUDE supports the following basic programmer types: Atmel's STK500, Atmel's AVRISP and AVRISP mkII devices, Atmel's STK600, Atmel's JTAG ICE (both mkI and mkII, the latter also in ISP mode), appnote avr910, appnote avr109 (including the AVR Butterfly), serial bit-bang adapters, and the PPI (parallel port interface). PPI represents a class of simple programmers where the programming lines are directly connected to the PC parallel port. Several pin configurations exist for several variations of the PPI programmers, and AVRDUDE can be configured to work with them by either specifying the appropriate programmer on the command line or by creating a new entry in its configuration file. All that's usually required for a new entry is to tell AVRDUDE which pins to use for each programming function.

A number of equally simple bit-bang programming adapters that connect to a serial port are supported as well, among them the popular Ponyprog serial adapter, and the DASA and DASA3 adapters that used to be supported by uisp(1). Note that these adapters are meant to be attached to a physical serial port. Connecting to a serial port emulated on top of USB is likely to not work at all, or to work abysmally slow.

The STK500, JTAG ICE, avr910, and avr109/butterfly use the serial port to communicate with the PC. The STK600, JTAG ICE mkII, AVRISP mkII, USBasp, and USBtinyISP programmers communicate through the USB, using `libusb` as a platform abstraction layer. The STK500, STK600, JTAG ICE, and avr910 contain on-board logic to control the programming of the target device. The avr109 bootloader implements a protocol similar to avr910, but is actually implemented in the boot area of the target's flash ROM, as opposed to being an external device. The fundamental difference between the two types lies in the protocol used to control the programmer. The avr910 protocol is very simplistic and can easily be used as the basis for a simple, home made programmer since the firmware is available online. On the other hand, the STK500 protocol is more robust and complicated and the firmware is not openly available. The JTAG ICE also uses a serial communication protocol which is similar to the STK500 firmware version 2 one. However, as the JTAG ICE is intended to allow on-chip debugging as well as memory programming, the protocol is more sophisticated. (The JTAG ICE mkII protocol can also be run on top of USB.) Only the memory programming functionality of the JTAG ICE is supported by AVRDUDE. For the JTAG ICE mkII, JTAG, debugWire and ISP mode are supported, provided it has a firmware revision of at least 4.14 (decimal). See below for the limitations of debugWire.

For ATxmega devices, the JTAG ICE mkII is supported in PDI mode, provided it has a revision 1 hardware and firmware version of at least 5.37 (decimal).

The AVR Dragon is supported in all modes (ISP, JTAG, HVSP, PP, debugWire). When used in JTAG and debugWire mode, the AVR Dragon behaves similar to a JTAG ICE mkII, so all device-specific comments for that device will apply as well. When used in ISP mode, the AVR Dragon behaves similar to an AVRISP mkII (or JTAG ICE mkII in ISP mode), so all device-specific comments will apply there. In particular, the Dragon starts out with a rather fast ISP clock frequency, so the `-B bitclock` option might be required to achieve a stable ISP communication. For ATxmega devices, the AVR Dragon is supported in PDI mode, provided it has a firmware version of at least 6.11 (decimal).

The Arduino (which is very similar to the STK500 1.x) is supported via its own programmer type specification “arduino”.

The BusPirate is a versatile tool that can also be used as an AVR programmer. A single BusPirate can be connected to up to 3 independent AVR's. See the section on *extended parameters* below for details.

The USBasp ISP and USBtinyISP adapters are also supported, provided AVRDUDE has been compiled with libusb support. They both feature simple firmware-only USB implementations, running on an ATmega8 (or ATmega88), or ATtiny2313, respectively.

1.1 History and Credits

AVRDUDE was written by Brian S. Dean under the name of AVRPROG to run on the FreeBSD Operating System. Brian renamed the software to be called AVRDUDE when interest grew in a Windows port of the software so that the name did not conflict with AVRPROG.EXE which is the name of Atmel's Windows programming software.

The AVRDUDE source now resides in the public CVS repository on savannah.gnu.org (<http://savannah.gnu.org/projects/avrdude/>), where it continues to be enhanced and ported to other systems. In addition to FreeBSD, AVRDUDE now runs on Linux and Windows. The developers behind the porting effort primarily were Ted Roth, Eric Weddington, and Joerg Wunsch.

And in the spirit of many open source projects, this manual also draws on the work of others. The initial revision was composed of parts of the original Unix manual page written by Joerg Wunsch, the original web site documentation by Brian Dean, and from the comments describing the fields in the AVRDUDE configuration file by Brian Dean. The texi formatting was modeled after that of the Simulavr documentation by Ted Roth.

2 Command Line Options

2.1 Option Descriptions

AVRDUDE is a command line tool, used as follows:

```
avrdude -p partno options ...
```

Command line options are used to control AVRDUDE's behaviour. The following options are recognized:

-p *partno*

This is the only mandatory option and it tells AVRDUDE what type of part (MCU) that is connected to the programmer. The *partno* parameter is the part's id listed in the configuration file. Specify -p ? to list all parts in the configuration file. If a part is unknown to AVRDUDE, it means that there is no config file entry for that part, but it can be added to the configuration file if you have the Atmel datasheet so that you can enter the programming specifications. Currently, the following MCU types are understood:

| | |
|----------|-----------------|
| 1200 | AT90S1200 |
| 2313 | AT90S2313 |
| 2333 | AT90S2333 |
| 2343 | AT90S2343 (*) |
| 4414 | AT90S4414 |
| 4433 | AT90S4433 |
| 4434 | AT90S4434 |
| 8515 | AT90S8515 |
| 8535 | AT90S8535 |
| c128 | AT90CAN128 |
| c32 | AT90CAN32 |
| c64 | AT90CAN64 |
| m103 | ATmega103 |
| m128 | ATmega128 |
| m1280 | ATmega1280 |
| m1281 | ATmega1281 |
| m1284p | ATmega1284P |
| m128rfa1 | ATmega128RFA1 |
| m16 | ATmega16 |
| m161 | ATmega161 |
| m162 | ATmega162 |
| m163 | ATmega163 |
| m164 | ATmega164 |
| m164p | ATmega164P |
| m168 | ATmega168 |
| m169 | ATmega169 |
| m2560 | ATmega2560 (**) |
| m2561 | ATmega2561 (**) |
| m32 | ATmega32 |
| m324p | ATmega324P |

| | |
|---------|----------------|
| m325 | ATmega325 |
| m3250 | ATmega3250 |
| m328p | ATmega328P |
| m329 | ATmega329 |
| m3290 | ATmega3290 |
| m329p | ATmega329P |
| m3290p | ATmega3290P |
| m32u4 | ATmega32U4 |
| m48 | ATmega48 |
| m64 | ATmega64 |
| m640 | ATmega640 |
| m644p | ATmega644P |
| m644 | ATmega644 |
| m645 | ATmega645 |
| m6450 | ATmega6450 |
| m649 | ATmega649 |
| m6490 | ATmega6490 |
| m8 | ATmega8 |
| m8515 | ATmega8515 |
| m8535 | ATmega8535 |
| m88 | ATmega88 |
| pwm2 | AT90PWM2 |
| pwm2b | AT90PWM2B |
| pwm3 | AT90PWM3 |
| pwm3b | AT90PWM3B |
| t10 | ATtiny10 |
| t12 | ATtiny12 (***) |
| t13 | ATtiny13 |
| t15 | ATtiny15 |
| t2313 | ATtiny2313 |
| t25 | ATtiny25 |
| t26 | ATtiny26 |
| t261 | ATtiny261 |
| t4 | ATtiny4 |
| t44 | ATtiny44 |
| t45 | ATtiny45 |
| t461 | ATtiny461 |
| t5 | ATtiny5 |
| t84 | ATtiny84 |
| t85 | ATtiny85 |
| t861 | ATtiny861 |
| t88 | ATtiny88 |
| t9 | ATtiny9 |
| ucr2 | AT32uca0512 |
| usb1286 | ATmega1286 |
| usb1287 | ATmega1287 |
| usb162 | ATmega162 |

| | |
|---------|------------------|
| usb646 | ATmega647 |
| usb647 | ATmega647 |
| usb82 | ATmega82 |
| x128a1 | ATxmega128A1 |
| x128a1d | ATxmega128A1revD |
| x128a3 | ATxmega128A3 |
| x128a4 | ATxmega128A4 |
| x16a4 | ATxmega16A4 |
| x192a1 | ATxmega192A1 |
| x192a3 | ATxmega192A3 |
| x256a1 | ATxmega256A1 |
| x256a3 | ATxmega256A3 |
| x256a3b | ATxmega256A3B |
| x32a4 | ATxmega32A4 |
| x64a1 | ATxmega64A1 |
| x64a3 | ATxmega64A3 |
| x64a4 | ATxmega64A4 |

(*) The AT90S2323 and ATtiny22 use the same algorithm.

(**) Flash addressing above 128 KB is not supported by all programming hardware. Known to work are jtag2, stk500v2, and bit-bang programmers.

(***) The ATtiny11 uses the same algorithm, but can only be programmed in high-voltage serial mode.

-b *baudrate*

Override the RS-232 connection baud rate specified in the respective programmer's entry of the configuration file.

-B *bitclock*

Specify the bit clock period for the JTAG interface or the ISP clock (JTAG ICE only). The value is a floating-point number in microseconds. The default value of the JTAG ICE results in about 1 microsecond bit clock period, suitable for target MCUs running at 4 MHz clock and above. Unlike certain parameters in the STK500, the JTAG ICE resets all its parameters to default values when the programming software signs off from the ICE, so for MCUs running at lower clock speeds, this parameter must be specified on the command-line.

-c *programmer-id*

Specify the programmer to be used. AVRDUDE knows about several common programmers. Use this option to specify which one to use. The *programmer-id* parameter is the programmer's id listed in the configuration file. Specify -c ? to list all programmers in the configuration file. If you have a programmer that is unknown to AVRDUDE, and the programmer is controlled via the PC parallel port, there's a good chance that it can be easily added to the configuration file without any code changes to AVRDUDE. Simply copy an existing entry and change the pin definitions to match that of the unknown programmer. Currently, the following programmer ids are understood and supported:

| | |
|---------|---------------------------------------|
| abcmini | ABCmini Board, aka Dick Smith HOTCHIP |
|---------|---------------------------------------|

| | |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| alf | Nightshade ALF-PgmAVR, http://nightshade.homeip.net/ |
| arduino | Arduino |
| board, | protocol |
| similar | to |
| STK500 1.x | |
| atisp | AT-ISP V1.1 programming cable for AVR-SDK1 from, http://micro-research.co.th/ |
| avr109 | Atmel AppNote AVR109 Boot Loader |
| avr910 | Atmel Low Cost Serial Programmer |
| avr911 | Atmel AppNote AVR911 AVROSP (an alias for avr109) |
| avrisp | Atmel AVR ISP (an alias for stk500) |
| avrispv2 | Atmel AVR ISP mkII in ISP mode, in PDI mode for ATxmega devices, or in TPI mode for ATtiny4/5/9/10 |
| avrispmkII | Atmel AVR ISP mkII (alias for stk500v2) |
| avrispv2 | Atmel AVR ISP, running a version 2.x firmware (an alias for stk500v2) |
| bascom | Bascom SAMPLE programming cable |
| blaster | Altera ByteBlaster |
| bsd | Brian Dean's Programmer, http://www.bsdhome.com/avrdude/ |
| buspirate | The Bus Pirate |
| butterfly | Atmel Butterfly Development Board |
| c2n232i | C2N232I, reset=dtr sck=!rts mosi=!txd miso=!cts, http://www.ktverkko.fi/~msmakela/8bit/c2n232/hardware/index.en.h |
| dapa | Direct AVR Parallel Access cable |
| dasa | serial port banging, reset=rts sck=dtr mosi=txd miso=cts |
| dasa3 | serial port banging, reset=!dtr sck=rts mosi=txd miso=cts |
| dragon_dw | AVR Dragon in debugWire mode |
| dragon_hvsp | AVR Dragon in high-voltage serial programming mode |
| dragon_isp | AVR Dragon in ISP mode |
| dragon_jtag | AVR Dragon in JTAG mode |
| dragon_pdi | AVR Dragon in PDI mode |
| dragon_pp | AVR Dragon in (high-voltage) parallel programming mode |
| dt006 | Dontronics DT006 |
| ere-isp-avr | ERE ISP-AVR, http://www.ere.co.th/download/sch050713.pdf |

| | |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| frank-stk200 | Frank's STK200 clone, http://electropol.free.fr/spip/spip.php?article15 |
| futurlec | Futurlec.com programming cable |
| jtag1 | Atmel JTAG ICE mkI, running at 115200 Bd |
| jtag1slow | Atmel JTAG ICE mkI, running at 19200 Bd |
| jtag2 | Atmel JTAG ICE mkII, running at 115200 Bd |
| jtag2avr32 | Atmel JTAG ICE mkII in AVR32 mode. |
| jtag2dw | Atmel JTAG ICE mkII in debugWire mode. |
| jtag2fast | Atmel JTAG ICE mkII, running at 115200 Bd |
| jtag2isp | Atmel JTAG ICE mkII in ISP mode. |
| jtag2pdi | Atmel JTAG ICE mkII in PDI mode. |
| jtag2slow | Atmel JTAG ICE mkII (default speed 19200 Bd) |
| jtagmkI | Atmel JTAG ICE mkI, running at 115200 Bd |
| jtagmkII | Atmel JTAG ICE mkII (default speed 19200 Bd) |
| jtagmkII_avr32 | Atmel JTAG ICE mkII in AVR32 mode. |
| mib510 | Crossbow MIB510 programming board |
| pavr | Jason Kyle's pAVR Serial Programmer |
| picoweb | Picoweb Programming Cable, http://www.picoweb.net/ |
| pony-stk200 | Pony Prog STK200 |
| ponyser | design ponyprog serial, reset=!txd sck=rts mosi=dtr miso=cts |
| siprolog | Lancos SI-Prog, http://www.lancos.com/siprogsch.html |
| sp12 | Steve Bolt's Programmer |
| stk200 | STK200 |
| stk500 | Atmel STK500, probing for either version 1.x or 2.x firmware |
| stk500hvsp | Atmel STK500 in high-voltage serial programming mode(version 2.x firmware only) |
| stk500pp | Atmel STK500 in parallel programming mode (ver- sion 2.xfirmware only) |
| stk500v1 | Atmel STK500, running a version 1.x firmware |
| stk500v2 | Atmel STK500, running a version 2.x firmware |
| stk600 | Atmel STK600 in ISP mode, in PDI mode for ATxmega devices, or in TPI mode for ATtiny4/5/9/10 |
| stk600hvsp | Atmel STK600 in high-voltage serial programming mode |
| stk600pp | Atmel STK600 in parallel programming mode |
| usbasp | USBasp, http://www.fischl.de/usbasp/ |
| usbtiny | USBTiny simple USB programmer, http://www.ladyada.net/make/usbtinyisp/ |
| xil | Xilinx JTAG cable |

-C *config-file*

Use the specified config file for configuration data. This file contains all programmer and part definitions that AVRDUDE knows about. If you have a programmer or part that AVRDUDE does not know about, you can add it to the config file (be sure and submit a patch back to the author so that it can be incorporated for the next version). If not specified, AVRDUDE reads the configuration file from `/etc/avrdude/avrdude.conf` (FreeBSD and Linux). See Appendix A for the method of searching for the configuration file for Windows.

-D Disable auto erase for flash. When the `-U` option with flash memory is specified, avrdude will perform a chip erase before starting any of the programming operations, since it generally is a mistake to program the flash without performing an erase first. This option disables that. Auto erase is not used for ATxmega devices as these devices can use page erase before writing each page so no explicit chip erase is required. Note however that any page not affected by the current operation will retain its previous contents.

-e Causes a chip erase to be executed. This will reset the contents of the flash ROM and EEPROM to the value `'0xff'`, and clear all lock bits. Except for ATxmega devices which can use page erase, it is basically a prerequisite command before the flash ROM can be reprogrammed again. The only exception would be if the new contents would exclusively cause bits to be programmed from the value `'1'` to `'0'`. Note that in order to reprogram EERPOM cells, no explicit prior chip erase is required since the MCU provides an auto-erase cycle in that case before programming the cell.

-E *exitspec* [, ...]

By default, AVRDUDE leaves the parallel port in the same state at exit as it has been found at startup. This option modifies the state of the `'/RESET'` and `'Vcc'` lines the parallel port is left at, according to the *exitspec* arguments provided, as follows:

| | |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| reset | The <code>'/RESET'</code> signal will be left activated at program exit, that is it will be held low, in order to keep the MCU in reset state afterwards. Note in particular that the programming algorithm for the AT90S1200 device mandates that the <code>'/RESET'</code> signal is active before powering up the MCU, so in case an external power supply is used for this MCU type, a previous invocation of AVRDUDE with this option specified is one of the possible ways to guarantee this condition. |
| noreset | The <code>'/RESET'</code> line will be deactivated at program exit, thus allowing the MCU target program to run while the programming hardware remains connected. |
| vcc | This option will leave those parallel port pins active (i. e. high) that can be used to supply <code>'Vcc'</code> power to the MCU. |
| novcc | This option will pull the <code>'Vcc'</code> pins of the parallel port down at program exit. |

Multiple *exitspec* arguments can be separated with commas.

- F** Normally, AVRDUDE tries to verify that the device signature read from the part is reasonable before continuing. Since it can happen from time to time that a device has a broken (erased or overwritten) device signature but is otherwise operating normally, this options is provided to override the check. Also, for programmers like the Atmel STK500 and STK600 which can adjust parameters local to the programming tool (independent of an actual connection to a target controller), this option can be used together with ‘-t’ to continue in terminal mode.
- i *delay*** For bitbang-type programmers, delay for approximately *delay* microseconds between each bit state change. If the host system is very fast, or the target runs off a slow clock (like a 32 kHz crystal, or the 128 kHz internal RC oscillator), this can become necessary to satisfy the requirement that the ISP clock frequency must not be higher than 1/4 of the CPU clock frequency. This is implemented as a spin-loop delay to allow even for very short delays. On Unix-style operating systems, the spin loop is initially calibrated against a system timer, so the number of microseconds might be rather realistic, assuming a constant system load while AVRDUDE is running. On Win32 operating systems, a preconfigured number of cycles per microsecond is assumed that might be off a bit for very fast or very slow machines.
- n** No-write - disables actually writing data to the MCU (useful for debugging AVRDUDE).
- O** Perform a RC oscillator run-time calibration according to Atmel application note AVR053. This is only supported on the STK500v2, AVRISP mkII, and JTAG ICE mkII hardware. Note that the result will be stored in the EEPROM cell at address 0.
- P *port*** Use port to identify the device to which the programmer is attached. Normally, the default parallel port is used, but if the programmer type normally connects to the serial port, the default serial port will be used. See Appendix A, Platform Dependent Information, to find out the default port names for your platform. If you need to use a different parallel or serial port, use this option to specify the alternate port name.

On Win32 operating systems, the parallel ports are referred to as lpt1 through lpt3, referring to the addresses 0x378, 0x278, and 0x3BC, respectively. If the parallel port can be accessed through a different address, this address can be specified directly, using the common C language notation (i. e., hexadecimal values are prefixed by 0x).

For the JTAG ICE mkII, if AVRDUDE has been built with libusb support, *port* may alternatively be specified as `usb[:serialno]`. In that case, the JTAG ICE mkII will be looked up on USB. If *serialno* is also specified, it will be matched against the serial number read from any JTAG ICE mkII found on USB. The match is done after stripping any existing colons from the given serial number, and right-to-left, so only the least significant bytes from the serial number need to be given. For a trick how to find out the serial numbers of all JTAG ICEs attached to USB, see [Section 2.3 \[Example Command Line Invocations\]](#), [page 15](#).

As the AVRISP mkII device can only be talked to over USB, the very same method of specifying the port is required there.

For the USB programmer "AVR-Doper" running in HID mode, the port must be specified as *avrdoper*. Libusb support is required on Unix but not on Windows. For more information about AVR-Doper see <http://www.obdev.at/avrusb/avrdoper.html>.

For programmers that attach to a serial port using some kind of higher level protocol (as opposed to bit-bang style programmers), *port* can be specified as *net:host:port*. In this case, instead of trying to open a local device, a TCP network connection to (TCP) *port* on *host* is established. The remote endpoint is assumed to be a terminal or console server that connects the network stream to a local serial port where the actual programmer has been attached to. The port is assumed to be properly configured, for example using a transparent 8-bit data connection without parity at 115200 Baud for a STK500.

This feature is currently not implemented for Win32 systems.

- q** Disable (or quell) output of the progress bar while reading or writing to the device. Specify it a second time for even quieter operation.
- u** Disables the default behaviour of reading out the fuses three times before programming, then verifying at the end of programming that the fuses have not changed. If you want to change fuses you will need to specify this option, as avrdude will see the fuses have changed (even though you wanted to) and will change them back for your "safety". This option was designed to prevent cases of fuse bits magically changing (usually called *safemode*).
- t** Tells AVRDUDE to enter the interactive "terminal" mode instead of up- or downloading files. See below for a detailed description of the terminal mode.

-U *memtype:op:filename[:format]*

Perform a memory operation. Multiple '-U' options can be specified in order to operate on multiple memories on the same command-line invocation. The *memtype* field specifies the memory type to operate on. Use the '-v' option on the command line or the **part** command from terminal mode to display all the memory types supported by a particular device. Typically, a device's memory configuration at least contains the memory types **flash** and **eeprom**. All memory types currently known are:

calibration

One or more bytes of RC oscillator calibration data.

eeprom The EEPROM of the device.

efuse The extended fuse byte.

flash The flash ROM of the device.

fuse The fuse byte in devices that have only a single fuse byte.

hfuse The high fuse byte.

lfuse The low fuse byte.

| | |
|--------------------------|---------------------------------------------------------------------------------------------------------|
| <code>lock</code> | The lock byte. |
| <code>signature</code> | The three device signature bytes (device ID). |
| <code>fuseN</code> | The fuse bytes of ATxmega devices, <i>N</i> is an integer number for each fuse supported by the device. |
| <code>application</code> | The application flash area of ATxmega devices. |
| <code>apptable</code> | The application table flash area of ATxmega devices. |
| <code>boot</code> | The boot flash area of ATxmega devices. |
| <code>prodsig</code> | The production signature (calibration) area of ATxmega devices. |
| <code>usersig</code> | The user signature area of ATxmega devices. |

The *op* field specifies what operation to perform:

| | |
|----------------|----------------------------------------------------------------------------------------|
| <code>r</code> | read the specified device memory and write to the specified file |
| <code>w</code> | read the specified file and write it to the specified device memory |
| <code>v</code> | read the specified device memory and the specified file and perform a verify operation |

The *filename* field indicates the name of the file to read or write. The *format* field is optional and contains the format of the file to read or write. Possible values are:

| | |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>i</code> | Intel Hex |
| <code>s</code> | Motorola S-record |
| <code>r</code> | raw binary; little-endian byte order, in the case of the flash ROM data |
| <code>m</code> | immediate mode; actual byte values specified on the command line, separated by commas or spaces in place of the <i>filename</i> field of the ‘-U’ option. This is useful for programming fuse bytes without having to create a single-byte file or enter terminal mode. If the number specified begins with <code>0x</code> , it is treated as a hex value. If the number otherwise begins with a leading zero (0) it is treated as octal. Otherwise, the value is treated as decimal. |
| <code>a</code> | auto detect; valid for input only, and only if the input is not provided at stdin. |
| <code>d</code> | decimal; this and the following formats are only valid on output. They generate one line of output for the respective memory section, forming a comma-separated list of the values. This can be particularly useful for subsequent processing, like for fuse bit settings. |
| <code>h</code> | hexadecimal; each value will get the string <code>0x</code> prepended. |
| <code>o</code> | octal; each value will get a <code>0</code> prepended unless it is less than 8 in which case it gets no prefix. |
| <code>b</code> | binary; each value will get the string <code>0b</code> prepended. |

The default is to use auto detection for input files, and raw binary format for output files.

Note that if *filename* contains a colon, the *format* field is no longer optional since the filename part following the colon would otherwise be misinterpreted as *format*.

As an abbreviation, the form `-U filename` is equivalent to specifying `-U flash:w:filename:a`. This will only work if *filename* does not have a colon in it.

`-v` Enable verbose output.

`-V` Disable automatic verify check when uploading data.

`-x extended_param`

Pass *extended_param* to the chosen programmer implementation as an extended parameter. The interpretation of the extended parameter depends on the programmer itself. See below for a list of programmers accepting extended parameters.

`-y` Tells AVRDUDE to use the last four bytes of the connected parts' EEPROM memory to track the number of times the device has been erased. When this option is used and the `'-e'` flag is specified to generate a chip erase, the previous counter will be saved before the chip erase, it is then incremented, and written back after the erase cycle completes. Presumably, the device would only be erased just before being programmed, and thus, this can be utilized to give an indication of how many erase-rewrite cycles the part has undergone. Since the FLASH memory can only endure a finite number of erase-rewrite cycles, one can use this option to track when a part is nearing the limit. The typical limit for Atmel AVR FLASH is 1000 cycles. Of course, if the application needs the last four bytes of EEPROM memory, this option should not be used.

`-Y cycles`

Instructs AVRDUDE to initialize the erase-rewrite cycle counter residing at the last four bytes of EEPROM memory to the specified value. If the application needs the last four bytes of EEPROM memory, this option should not be used.

2.2 Programmers accepting extended parameters

JTAG ICE mkII

AVR Dragon

When using the JTAG ICE mkII or AVR Dragon in JTAG mode, the following extended parameter is accepted:

`'jtagchain=UB,UA,BB,BA'`

Setup the JTAG scan chain for *UB* units before, *UA* units after, *BB* bits before, and *BA* bits after the target AVR, respectively. Each AVR unit within the chain shifts by 4 bits. Other JTAG units might require a different bit shift count.

AVR910

The AVR910 programmer type accepts the following extended parameter:

`'devcode=VALUE'`

Override the device code selection by using *VALUE* as the device code. The programmer is not queried for the list of supported device codes, and the specified *VALUE* is not verified but used directly within the T command sent to the programmer. *VALUE* can be specified using the conventional number notation of the C programming language.

`'no_blockmode'`

Disables the default checking for block transfer capability. Use `'no_blockmode'` only if your 'AVR910' programmer creates errors during initial sequence.

BusPirate

The BusPirate programmer type accepts the following extended parameters:

`'reset=cs,aux,aux2'`

The default setup assumes the BusPirate's CS output pin connected to the RESET pin on AVR side. It is however possible to have multiple AVRs connected to the same BP with MISO, MOSI and SCK lines common for all of them. In such a case one AVR should have its RESET connected to BusPirate's *CS* pin, second AVR's RESET connected to BusPirate's *AUX* pin and if your BusPirate has an *AUX2* pin (only available on BusPirate version v1a with firmware 3.0 or newer) use that to activate RESET on the third AVR.

It may be a good idea to decouple the BusPirate and the AVR's SPI buses from each other using a 3-state bus buffer. For example 74HC125 or 74HC244 are some good candidates with the latches driven by the appropriate reset pin (cs, aux or aux2). Otherwise the SPI traffic in one active circuit may interfere with programming the AVR in the other design.

`'speed=0..7'`

0 30 kHz (default)

| | |
|---|---------|
| 1 | 125 kHz |
| 2 | 250 kHz |
| 3 | 1 MHz |
| 4 | 2 MHz |
| 5 | 2.6 MHz |
| 6 | 4 MHz |
| 7 | 8 MHz |

`'ascii'` Use ASCII mode even when the firmware supports BinMode (binary mode). BinMode is supported in firmware 2.7 and newer, older FW's either don't have BinMode or their BinMode is buggy. ASCII mode is slower and makes the above `'reset='` and `'speed='` parameters unavailable.

2.3 Example Command Line Invocations

Download the file `diag.hex` to the ATmega128 chip using the STK500 programmer connected to the default serial port:

```
% avrdude -p m128 -c stk500 -e -U flash:w:diag.hex

avrdude: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.03s

avrdude: Device signature = 0x1e9702
avrdude: erasing chip
avrdude: done.
avrdude: performing op: 1, flash, 0, diag.hex
avrdude: reading input file "diag.hex"
avrdude: input file diag.hex auto detected as Intel Hex
avrdude: writing flash (19278 bytes):

Writing | ##### | 100% 7.60s

avrdude: 19456 bytes of flash written
avrdude: verifying flash memory against diag.hex:
avrdude: load data flash data from input file diag.hex:
avrdude: input file diag.hex auto detected as Intel Hex
avrdude: input file diag.hex contains 19278 bytes
avrdude: reading on-chip flash data:

Reading | ##### | 100% 6.83s

avrdude: verifying ...
avrdude: 19278 bytes of flash verified

avrdude: safemode: Fuses OK

avrdude done. Thank you.

%
```

Upload the flash memory from the ATmega128 connected to the STK500 programmer and save it in raw binary format in the file named `c:/diag flash.bin`:

```
% avrdude -p m128 -c stk500 -U flash:r:"c:/diag flash.bin":r
avrdude: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.03s

avrdude: Device signature = 0x1e9702
avrdude: reading flash memory:

Reading | ##### | 100% 46.10s

avrdude: writing output file "c:/diag flash.bin"

avrdude: safemode: Fuses OK

avrdude done.  Thank you.

%
```

Using the default programmer, download the file `diag.hex` to flash, `eeeprom.hex` to EEPROM, and set the Extended, High, and Low fuse bytes to `0xff`, `0x89`, and `0x2e` respectively:

```
% avrdude -p m128 -u -U flash:w:diag.hex \  
> -U eeprom:w:eeeprom.hex \  
> -U efuse:w:0xff:m \  
> -U hfuse:w:0x89:m \  
> -U lfuse:w:0x2e:m  
  
avrdude: AVR device initialized and ready to accept instructions  
  
Reading | ##### | 100% 0.03s  
  
avrdude: Device signature = 0x1e9702  
avrdude: NOTE: FLASH memory has been specified, an erase cycle will be performed  
To disable this feature, specify the -D option.  
avrdude: erasing chip  
avrdude: reading input file "diag.hex"  
avrdude: input file diag.hex auto detected as Intel Hex  
avrdude: writing flash (19278 bytes):  
  
Writing | ##### | 100% 7.60s  
  
avrdude: 19456 bytes of flash written  
avrdude: verifying flash memory against diag.hex:  
avrdude: load data flash data from input file diag.hex:  
avrdude: input file diag.hex auto detected as Intel Hex  
avrdude: input file diag.hex contains 19278 bytes  
avrdude: reading on-chip flash data:  
  
Reading | ##### | 100% 6.84s  
  
avrdude: verifying ...  
avrdude: 19278 bytes of flash verified  
  
[ ... other memory status output skipped for brevity ... ]  
  
avrdude done. Thank you.  
  
%
```

Connect to the JTAG ICE mkII which serial number ends up in 1C37 via USB, and enter terminal mode:

```
% avrdude -c jtag2 -p m649 -P usb:1c:37 -t
avrdude: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.03s

avrdude: Device signature = 0x1e9603

[ ... terminal mode output skipped for brevity ... ]

avrdude done.  Thank you.
```

List the serial numbers of all JTAG ICEs attached to USB. This is done by specifying an invalid serial number, and increasing the verbosity level.

```
% avrdude -c jtag2 -p m128 -P usb:xx -v
[...]
    Using Port          : usb:xxx
    Using Programmer    : jtag2
avrdude: usbdev_open(): Found JTAG ICE, serno: 00A000001C6B
avrdude: usbdev_open(): Found JTAG ICE, serno: 00A000001C3A
avrdude: usbdev_open(): Found JTAG ICE, serno: 00A000001C30
avrdude: usbdev_open(): did not find any (matching) USB device "usb:xxx"
```

3 Terminal Mode Operation

AVRDUDE has an interactive mode called *terminal mode* that is enabled by the ‘-t’ option. This mode allows one to enter interactive commands to display and modify the various device memories, perform a chip erase, display the device signature bytes and part parameters, and to send raw programming commands. Commands and parameters may be abbreviated to their shortest unambiguous form. Terminal mode also supports a command history so that previously entered commands can be recalled and edited.

3.1 Terminal Mode Commands

The following commands are implemented:

| | |
|-------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>dump memtype addr nbytes</code> | Read <i>nbytes</i> from the specified memory area, and display them in the usual hexadecimal and ASCII form. |
| <code>dump</code> | Continue dumping the memory contents for another <i>nbytes</i> where the previous dump command left off. |
| <code>write memtype addr byte1 ... byteN</code> | Manually program the respective memory cells, starting at address <i>addr</i> , using the values <i>byte1</i> through <i>byteN</i> . This feature is not implemented for bank-addressed memories such as the flash memory of ATMega devices. |
| <code>erase</code> | Perform a chip erase. |
| <code>send b1 b2 b3 b4</code> | Send raw instruction codes to the AVR device. If you need access to a feature of an AVR part that is not directly supported by AVRDUDE, this command allows you to use it, even though AVRDUDE does not implement the command. When using direct SPI mode, up to 3 bytes can be omitted. |
| <code>sig</code> | Display the device signature bytes. |
| <code>spi</code> | Enter direct SPI mode. The <i>pgmled</i> pin acts as slave select. <i>Only supported on parallel bitbang programmers.</i> |
| <code>part</code> | Display the current part settings and parameters. Includes chip specific information including all memory types supported by the device, read/write timing, etc. |
| <code>pgm</code> | Return to programming mode (from direct SPI mode). |
| <code>?</code> | |
| <code>help</code> | Give a short on-line summary of the available commands. |
| <code>quit</code> | Leave terminal mode and thus AVRDUDE. |

In addition, the following commands are supported on the STK500 and STK600 programmer:

| | |
|----------------------------|----------------------------------------------------------|
| <code>vtarg voltage</code> | Set the target’s supply voltage to <i>voltage</i> Volts. |
|----------------------------|----------------------------------------------------------|

varef [channel] voltage

Set the adjustable voltage source to *voltage* Volts. This voltage is normally used to drive the target's *Aref* input on the STK500 and STK600. The STK600 offers two reference voltages, which can be selected by the optional parameter *channel* (either 0 or 1).

fosc freq [M|k]

Set the master oscillator to *freq* Hz. An optional trailing letter **M** multiplies by 1E6, a trailing letter **k** by 1E3.

fosc off Turn the master oscillator off.

sck period

STK500 and STK600 only: Set the SCK clock period to *period* microseconds.

JTAG ICE only: Set the JTAG ICE bit clock period to *period* microseconds. Note that unlike STK500 settings, this setting will be reverted to its default value (approximately 1 microsecond) when the programming software signs off from the JTAG ICE. This parameter can also be used on the JTAG ICE mkII to specify the ISP clock period when operating the ICE in ISP mode.

parms *STK500 and STK600 only:* Display the current voltage and master oscillator parameters.

JTAG ICE only: Display the current target supply voltage and JTAG bit clock rate/period.

3.2 Terminal Mode Examples

Display part parameters, modify eeprom cells, perform a chip erase:


```
% avrdude -p m128 -c stk500 -t

avrdude: AVR device initialized and ready to accept instructions
avrdude: Device signature = 0x1e9702
avrdude: current erase-rewrite cycle count is 52 (if being tracked)
avrdude> part
>>> part

AVR Part           : ATMEGA128
Chip Erase delay   : 9000 us
PAGEL              : PD7
BS2                : PA0
RESET disposition  : dedicated
RETRY pulse        : SCK
serial program mode : yes
parallel program mode : yes
Memory Detail      :

      Memory Type Paged  Size      Page
      -----
      Size #Pages MinW  MaxW      Polled
      -----
      ReadBack

eeprom      no          4096       8        0    9000   9000 0xff 0xff
flash       yes       131072    256     512   4500   9000 0xff 0x00
lfuse       no           1         0         0         0    0x00 0x00
hfuse       no           1         0         0         0    0x00 0x00
efuse       no           1         0         0         0    0x00 0x00
lock        no           1         0         0         0    0x00 0x00
calibration no           1         0         0         0    0x00 0x00
signature   no           3         0         0         0    0x00 0x00

avrdude> dump eeprom 0 16
>>> dump eeprom 0 16
0000  ff ff ff ff ff ff ff ff  ff ff ff ff ff ff ff ff  |.....|

avrdude> write eeprom 0 1 2 3 4
>>> write eeprom 0 1 2 3 4

avrdude> dump eeprom 0 16
>>> dump eeprom 0 16
0000  01 02 03 04 ff ff ff ff  ff ff ff ff ff ff ff ff  |.....|

avrdude> erase
>>> erase
avrdude: erasing chip
avrdude> dump eeprom 0 16
>>> dump eeprom 0 16
0000  ff ff ff ff ff ff ff ff  ff ff ff ff ff ff ff ff  |.....|

avrdude>
```

Program the fuse bits of an ATmega128 (disable M103 compatibility, enable high speed external crystal, enable brown-out detection, slowly rising power). Note since we are working with fuse bits the `-u` (unsafe) option is specified, which allows you to modify the fuse bits. First display the factory defaults, then reprogram:

```
% avrdude -p m128 -u -c stk500 -t

avrdude: AVR device initialized and ready to accept instructions
avrdude: Device signature = 0x1e9702
avrdude: current erase-rewrite cycle count is 52 (if being tracked)
avrdude> d efuse
>>> d efuse
0000 fd |. |

avrdude> d hfuse
>>> d hfuse
0000 99 |. |

avrdude> d lfuse
>>> d lfuse
0000 e1 |. |

avrdude> w efuse 0 0xff
>>> w efuse 0 0xff

avrdude> w hfuse 0 0x89
>>> w hfuse 0 0x89

avrdude> w lfuse 0 0x2f
>>> w lfuse 0 0x2f

avrdude>
```

4 Configuration File

AVRDUDE reads a configuration file upon startup which describes all of the parts and programmers that it knows about. The advantage of this is that if you have a chip that is not currently supported by AVRDUDE, you can add it to the configuration file without waiting for a new release of AVRDUDE. Likewise, if you have a parallel port programmer that is not supported by AVRDUDE, chances are good that you can copy an existing programmer definition, and with only a few changes, make your programmer work with AVRDUDE.

AVRDUDE first looks for a system wide configuration file in a platform dependent location. On Unix, this is usually `/etc/avrdude/avrdude.conf`, while on Windows it is usually in the same location as the executable file. The name of this file can be changed using the `‘-C’` command line option. After the system wide configuration file is parsed, AVRDUDE looks for a per-user configuration file to augment or override the system wide defaults. On Unix, the per-user file is `.avrduderc` within the user’s home directory. On Windows, this file is the `avrdude.rc` file located in the same directory as the executable.

4.1 AVRDUDE Defaults

```
default_parallel = "default-parallel-device";
```

Assign the default parallel port device. Can be overridden using the `‘-P’` option.

```
default_serial = "default-serial-device";
```

Assign the default serial port device. Can be overridden using the `‘-P’` option.

```
default_programmer = "default-programmer-id";
```

Assign the default programmer id. Can be overridden using the `‘-c’` option.

4.2 Programmer Definitions

The format of the programmer definition is as follows:

```
programmer
  id      = <id1> [, <id2> [, <id3>] ...] ; # <idN> are quoted strings
  desc    = <description> ;                  # quoted string
  type    = par | stk500 ;                    # programmer type
  baudrate = <num> ;                          # baudrate for serial ports
  vcc     = <num1> [, <num2> ... ] ;          # pin number(s)
  reset   = <num> ;                           # pin number
  sck     = <num> ;                           # pin number
  mosi    = <num> ;                           # pin number
  miso    = <num> ;                           # pin number
  errled  = <num> ;                           # pin number
  rdyled  = <num> ;                           # pin number
  pgmled  = <num> ;                           # pin number
  vfyled  = <num> ;                           # pin number
;
```

4.3 Part Definitions

```
part
  id      = <id> ;                            # quoted string
  desc    = <description> ;                    # quoted string
```

```

devicecode      = <num> ;                # numeric
chip_erase_delay = <num> ;                # micro-seconds
pagel           = <num> ;                # pin name in hex, i.e., 0xD7
bs2            = <num> ;                # pin name in hex, i.e., 0xA0
reset           = dedicated | io;
retry_pulse     = reset | sck;
pgm_enable      = <instruction format> ;
chip_erase      = <instruction format> ;
memory <memtype>
    paged       = <yes/no> ;            # yes / no
    size        = <num> ;                # bytes
    page_size   = <num> ;                # bytes
    num_pages   = <num> ;                # numeric
    min_write_delay = <num> ;            # micro-seconds
    max_write_delay = <num> ;            # micro-seconds
    readback_p1 = <num> ;                # byte value
    readback_p2 = <num> ;                # byte value
    pwroff_after_write = <yes/no> ;    # yes / no
    read        = <instruction format> ;
    write       = <instruction format> ;
    read_lo     = <instruction format> ;
    read_hi     = <instruction format> ;
    write_lo    = <instruction format> ;
    write_hi    = <instruction format> ;
    loadpage_lo = <instruction format> ;
    loadpage_hi = <instruction format> ;
    writepage   = <instruction format> ;
;
;

```

4.3.1 Instruction Format

Instruction formats are specified as a comma separated list of string values containing information (bit specifiers) about each of the 32 bits of the instruction. Bit specifiers may be one of the following formats:

- 1 The bit is always set on input as well as output
- 0 the bit is always clear on input as well as output
- x the bit is ignored on input and output
- a the bit is an address bit, the bit-number matches this bit specifier's position within the current instruction byte
- aN the bit is the Nth address bit, bit-number = N, i.e., a12 is address bit 12 on input, a0 is address bit 0.
- i the bit is an input data bit
- o the bit is an output data bit

Each instruction must be composed of 32 bit specifiers. The instruction specification closely follows the instruction data provided in Atmel's data sheets for their parts. For example, the EEPROM read and write instruction for an AT90S2313 AVR part could be encoded as:

```
read = "1 0 1 0 0 0 0 0 x x x x x x x x",
```

```

"x a6 a5 a4 a3 a2 a1 a0 o o o o o o o o";

write = "1 1 0 0 0 0 0 0 x x x x x x x x",
"x a6 a5 a4 a3 a2 a1 a0 i i i i i i i i";

```

4.4 Other Notes

- The `devicecode` parameter is the device code used by the STK500 and is obtained from the software section (`avr061.zip`) of Atmel's AVR061 application note available from <http://www.atmel.com/atmel/acrobat/doc2525.pdf>.
- Not all memory types will implement all instructions.
- AVR Fuse bits and Lock bits are implemented as a type of memory.
- Example memory types are: `flash`, `eeprom`, `fuse`, `lfuse` (low fuse), `hfuse` (high fuse), `efuse` (extended fuse), `signature`, `calibration`, `lock`.
- The memory type specified on the AVRDUDE command line must match one of the memory types defined for the specified chip.
- The `pwroff_after_write` flag causes AVRDUDE to attempt to power the device off and back on after an unsuccessful write to the affected memory area if VCC programmer pins are defined. If VCC pins are not defined for the programmer, a message indicating that the device needs a power-cycle is printed out. This flag was added to work around a problem with the at90s4433/2333's; see the at90s4433 errata at: <http://www.atmel.com/atmel/acrobat/doc1280.pdf>
- The boot loader from application note AVR109 (and thus also the AVR Butterfly) does not support writing of fuse bits. Writing lock bits is supported, but is restricted to the boot lock bits (BLBxx). These are restrictions imposed by the underlying SPM instruction that is used to program the device from inside the boot loader. Note that programming the boot lock bits can result in a "shoot-into-your-foot" scenario as the only way to unprogram these bits is a chip erase, which will also erase the boot loader code.

The boot loader implements the "chip erase" function by erasing the flash pages of the application section.

Reading fuse and lock bits is fully supported.

Note that due to the inability to write the fuse bits, the safemode functionality does not make sense for these boot loaders.

5 Programmer Specific Information

5.1 Atmel STK600

The following devices are supported by the respective STK600 routing and socket card:

| Routing card | Socket card | Devices |
|------------------|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | STK600-ATTINY10 | ATtiny4 ATtiny5 ATtiny9 ATtiny10 |
| STK600-RC008T-2 | STK600-DIP | ATtiny11 ATtiny12 ATtiny13 ATtiny13A ATtiny25 ATtiny45 ATtiny85 |
| STK600-RC008T-7 | STK600-DIP | ATtiny15 |
| STK600-RC014T-42 | STK600-SOIC | ATtiny20 |
| STK600-RC020T-1 | STK600-DIP | ATtiny2313 ATtiny2313A ATtiny4313 |
| | STK600-TinyX3U | ATtiny43U |
| STK600-RC014T-12 | STK600-DIP | ATtiny24 ATtiny44 ATtiny84 ATtiny24A ATtiny44A |
| STK600-RC020T-8 | STK600-DIP | ATtiny26 ATtiny261 ATtiny261A AT- tiny461 ATtiny861 ATtiny861A |
| STK600-RC020T-43 | STK600-SOIC | ATtiny261 ATtiny261A ATtiny461 AT- tiny461A ATtiny861 ATtiny861A |
| STK600-RC020T-23 | STK600-SOIC | ATtiny87 ATtiny167 |
| STK600-RC028T-3 | STK600-DIP | ATtiny28 |
| STK600-RC028M-6 | STK600-DIP | ATtiny48 ATtiny88 ATmega8 ATmega8A ATmega48 ATmega88 ATmega168 AT- mega48P ATmega48PA ATmega88P AT- mega88PA ATmega168P ATmega168PA ATmega328P |
| | QT600-ATTINY88- QT8 | ATtiny88 |
| STK600-RC040M-4 | STK600-DIP | ATmega8515 ATmega162 |
| STK600-RC044M-30 | STK600-TQFP44 | ATmega8515 ATmega162 |
| STK600-RC040M-5 | STK600-DIP | ATmega8535 ATmega16 ATmega16A AT- mega32 ATmega32A ATmega164P AT- mega164PA ATmega324P ATmega324PA ATmega644 ATmega644P ATmega644PA ATmega1284P |
| STK600-RC044M-31 | STK600-TQFP44 | ATmega8535 ATmega16 ATmega16A AT- mega32 ATmega32A ATmega164P AT- mega164PA ATmega324P ATmega324PA ATmega644 ATmega644P ATmega644PA ATmega1284P |
| | QT600-ATMEGA324- QM64 | ATmega324PA |
| STK600-RC032M-29 | STK600-TQFP32 | ATmega8 ATmega8A ATmega48 ATmega88 ATmega168 ATmega48P ATmega48PA ATmega88P ATmega88PA ATmega168P ATmega168PA ATmega328P |

| | | |
|------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| STK600-RC064M-9 | STK600-TQFP64 | ATmega64 ATmega64A ATmega128 ATmega128A ATmega1281 ATmega2561 AT90CAN32 AT90CAN64 AT90CAN128 |
| STK600-RC064M-10 | STK600-TQFP64 | ATmega165 ATmega165P ATmega169 AT- mega169P ATmega169PA ATmega325 AT- mega325P ATmega329 ATmega329P AT- mega645 ATmega649 ATmega649P |
| STK600-RC100M-11 | STK600-TQFP100 STK600- ATMEGA2560 | ATmega640 ATmega1280 ATmega2560 ATmega2560 |
| STK600-RC100M-18 | STK600-TQFP100 | ATmega3250 ATmega3250P ATmega3290 ATmega3290P ATmega6450 ATmega6490 |
| STK600-RC032U-20 | STK600-TQFP32 | AT90USB82 AT90USB162 ATmega8U2 ATmega16U2 ATmega32U2 |
| STK600-RC044U-25 | STK600-TQFP44 | ATmega16U4 ATmega32U4 |
| STK600-RC064U-17 | STK600-TQFP64 | ATmega32U6 AT90USB646 AT90USB1286 AT90USB647 AT90USB1287 |
| STK600-RCPWM-22 | STK600-TQFP32 | ATmega32C1 ATmega64C1 ATmega16M1 ATmega32M1 ATmega64M1 |
| STK600-RCPWM-19 | STK600-SOIC | AT90PWM2 AT90PWM3 AT90PWM2B AT90PWM3B AT90PWM216 AT90PWM316 |
| STK600-RCPWM-26 | STK600-SOIC | AT90PWM81 |
| STK600-RC044M-24 | STK600-TSSOP44 STK600-HVE2 STK600- ATMEGA128RFA1 | ATmega16HVB ATmega32HVB ATmega64HVE ATmega128RFA1 |
| STK600-RC100X-13 | STK600-TQFP100 STK600- ATXMEGA1281A1 QT600- ATXMEGA128A1- QT16 | ATxmega64A1 ATxmega128A1 ATxmega128A1_revD ATxmega128A1U ATxmega128A1 ATxmega128A1 |
| STK600-RC064X-14 | STK600-TQFP64 | ATxmega64A3 ATxmega128A3 ATxmega256A3 ATxmega64D3 ATxmega128D3 ATxmega192D3 ATxmega256D3 |
| STK600-RC064X-14 | STK600-MLF64 | ATxmega256A3B |
| STK600-RC044X-15 | STK600-TQFP44 STK600-ATXMEGAT0 STK600-uC3-144 | ATxmega32A4 ATxmega16A4 ATxmega16D4 ATxmega32D4 ATxmega32T0 AT32UC3A0512 AT32UC3A0256 AT32UC3A0128 |

| | | | |
|---------------------|---------------------|---------------------------------------------------------------|--------------------------------------------------|
| STK600-RCUC3A144-33 | STK600-TQFP144 | AT32UC3A0512 AT32UC3A0128 | AT32UC3A0256 |
| STK600-RCuC3A100-28 | STK600-TQFP100 | AT32UC3A1512 AT32UC3A1128 | AT32UC3A1256 |
| STK600-RCuC3B0-21 | STK600-TQFP64-2 | AT32UC3B0256 AT32UC3B0512 AT32UC3B064 | AT32UC3B0512RevC AT32UC3B0128 AT32UC3D1128 |
| STK600-RCuC3B48-27 | STK600-TQFP48 | AT32UC3B1256 | AT32UC3B164 |
| STK600-RCUC3A144-32 | STK600-TQFP144 | AT32UC3A3512 AT32UC3A3128 AT32UC3A3256S AT32UC3A364S | AT32UC3A3256 AT32UC3A364 AT32UC3A3128S |
| STK600-RCUC3C0-36 | STK600-TQFP144 | AT32UC3C0512 AT32UC3C0128 | AT32UC3C0256 AT32UC3C064 |
| STK600-RCUC3C1-38 | STK600-TQFP100 | AT32UC3C1512 AT32UC3C1128 | AT32UC3C1256 AT32UC3C164 |
| STK600-RCUC3C2-40 | STK600-TQFP64-2 | AT32UC3C2512 AT32UC3C2128 | AT32UC3C2256 AT32UC3C264 |
| STK600-RCUC3C0-37 | STK600-TQFP144 | AT32UC3C0512 AT32UC3C0128 | AT32UC3C0256 AT32UC3C064 |
| STK600-RCUC3C1-39 | STK600-TQFP100 | AT32UC3C1512 AT32UC3C1128 | AT32UC3C1256 AT32UC3C164 |
| STK600-RCUC3C2-41 | STK600-TQFP64-2 | AT32UC3C2512 AT32UC3C2128 | AT32UC3C2256 AT32UC3C264 |
| STK600-RCUC3L0-34 | STK600-TQFP48 | AT32UC3L064 AT32UC3L016 | AT32UC3L032 |
| | QT600-AT32UC3L-QM64 | AT32UC3L064 | |

Ensure the correct socket and routing card are mounted *before* powering on the STK600. While the STK600 firmware ensures the socket and routing card mounted match each other (using a table stored internally in nonvolatile memory), it cannot handle the case where a wrong routing card is used, e. g. the routing card STK600-RC040M-5 (which is meant for 40-pin DIP AVR's that have an ADC, with the power supply pins in the center of the package) was used but an ATmega8515 inserted (which uses the “industry standard” pinout with Vcc and GND at opposite corners).

Note that for devices that use the routing card STK600-RC008T-2, in order to use ISP mode, the jumper for AREF0 must be removed as it would otherwise block one of the ISP signals. High-voltage serial programming can be used even with that jumper installed.

The ISP system of the STK600 contains a detection against shortcuts and other wiring errors. AVRDUDE initiates a connection check before trying to enter ISP programming mode, and display the result if the target is not found ready to be ISP programmed.

High-voltage programming requires the target voltage to be set to at least 4.5 V in order to work. This can be done using *Terminal Mode*, see [Chapter 3 \[Terminal Mode Operation\]](#), [page 19](#).

Appendix A Platform Dependent Information

A.1 Unix

A.1.1 Unix Installation

To build and install from the source tarball on Unix like systems:

```
$ gunzip -c avrdude-5.10.tar.gz | tar xf -
$ cd avrdude-5.10
$ ./configure
$ make
$ su root -c 'make install'
```

The default location of the install is into `/usr/local` so you will need to be sure that `/usr/local/bin` is in your `PATH` environment variable.

If you do not have root access to your system, you can do the the following instead:

```
$ gunzip -c avrdude-5.10.tar.gz | tar xf -
$ cd avrdude-5.10
$ ./configure --prefix=$HOME/local
$ make
$ make install
```

A.1.1.1 FreeBSD Installation

AVRDUDE is installed via the FreeBSD Ports Tree as follows:

```
% su - root
# cd /usr/ports/devel/avrdude
# make install
```

If you wish to install from a pre-built package instead of the source, you can use the following instead:

```
% su - root
# pkg_add -r avrdude
```

Of course, you must be connected to the Internet for these methods to work, since that is where the source as well as the pre-built package is obtained.

A.1.1.2 Linux Installation

On rpm based Linux systems (such as RedHat, SUSE, Mandrake, etc), you can build and install the rpm binaries directly from the tarball:

```
$ su - root
# rpmbuild -tb avrdude-5.10.tar.gz
# rpm -Uvh /usr/src/redhat/RPMS/i386/avrdude-5.10-1.i386.rpm
```

Note that the path to the resulting rpm package, differs from system to system. The above example is specific to RedHat.

A.1.2 Unix Configuration Files

When AVRDUDE is build using the default ‘`--prefix`’ configure option, the default configuration file for a Unix system is located at `/etc/avrdude/avrdude.conf`. This can be overridden by using the ‘`-C`’ command line option. Additionally, the user’s home directory is searched for a file named `.avrduderc`, and if found, is used to augment the system default configuration file.

A.1.2.1 FreeBSD Configuration Files

When AVRDUDE is installed using the FreeBSD ports system, the system configuration file is always `/etc/avrdude/avrdude.conf`.

A.1.2.2 Linux Configuration Files

When AVRDUDE is installed using from an rpm package, the system configuration file will be always be `/etc/avrdude/avrdude.conf`.

A.1.3 Unix Port Names

The parallel and serial port device file names are system specific. The following table lists the default names for a given system.

| System | Default Parallel Port | Default Serial Port |
|---------|------------------------------|--------------------------|
| FreeBSD | <code>/dev/ppi0</code> | <code>/dev/cuad0</code> |
| Linux | <code>/dev/parport0</code> | <code>/dev/ttyS0</code> |
| Solaris | <code>/dev/printers/0</code> | <code>/dev/term/a</code> |

On FreeBSD systems, AVRDUDE uses the `ppi(4)` interface for accessing the parallel port and the `sio(4)` driver for serial port access.

On Linux systems, AVRDUDE uses the `ppdev` interface for accessing the parallel port and the `tty` driver for serial port access.

On Solaris systems, AVRDUDE uses the `ecpp(7D)` driver for accessing the parallel port and the `asy(7D)` driver for serial port access.

A.1.4 Unix Documentation

AVRDUDE installs a manual page as well as info, HTML and PDF documentation. The manual page is installed in `/usr/local/man/man1` area, while the HTML and PDF documentation is installed in `/usr/local/share/doc/avrdude` directory. The info manual is installed in `/usr/local/info/avrdude.info`.

Note that these locations can be altered by various configure options such as ‘`--prefix`’.

A.2 Windows

A.2.1 Installation

A Windows executable of `avrdude` is included in WinAVR which can be found at <http://sourceforge.net/projects/winavr>. WinAVR is a suite of executable, open source software development tools for the AVR for the Windows platform.

To build `avrdude` from the source You must have Cygwin (<http://www.cygwin.com/>).

To build and install from the source tarball for Windows (using Cygwin):

```
$ set PREFIX=<your install directory path>
$ export PREFIX
$ gunzip -c avrdude-5.10.tar.gz | tar xf -
$ cd avrdude-5.10
$ ./configure LDFLAGS="-static" --prefix=$PREFIX --datadir=$PREFIX
--sysconfdir=$PREFIX/bin --enable-versioned-doc=no
$ make
$ make install
```

A.2.2 Configuration Files

A.2.2.1 Configuration file names

AVRDUDE on Windows looks for a system configuration file name of `avrdude.conf` and looks for a user override configuration file of `avrdude.rc`.

A.2.2.2 How AVRDUDE finds the configuration files.

AVRDUDE on Windows has a different way of searching for the system and user configuration files. Below is the search method for locating the configuration files:

1. The directory from which the application loaded.
2. The current directory.
3. The Windows system directory. On Windows NT, the name of this directory is `SYSTEM32`.
4. Windows NT: The 16-bit Windows system directory. The name of this directory is `SYSTEM`.
5. The Windows directory.
6. The directories that are listed in the `PATH` environment variable.

A.2.3 Port Names

A.2.3.1 Serial Ports

When you select a serial port (i.e. when using an STK500) use the Windows serial port device names such as: `com1`, `com2`, etc.

A.2.3.2 Parallel Ports

AVRDUDE will accept 3 Windows parallel port names: `lpt1`, `lpt2`, or `lpt3`. Each of these names corresponds to a fixed parallel port base address:

| | |
|-------------------|--------------------|
| <code>lpt1</code> | <code>0x378</code> |
| <code>lpt2</code> | <code>0x278</code> |
| <code>lpt3</code> | <code>0x3BC</code> |

On your desktop PC, `lpt1` will be the most common choice. If you are using a laptop, you might have to use `lpt3` instead of `lpt1`. Select the name of the port the corresponds to the base address of the parallel port that you want.

If the parallel port can be accessed through a different address, this address can be specified directly, using the common C language notation (i. e., hexadecimal values are prefixed by 0x).

A.2.4 Using the parallel port

A.2.4.1 Windows NT/2K/XP

On Windows NT, 2000, and XP user applications cannot directly access the parallel port. However, kernel mode drivers can access the parallel port. giveio.sys is a driver that can allow user applications to set the state of the parallel port pins.

Before using AVRDUDE, the giveio.sys driver must be loaded. The accompanying command-line program, loaddrv.exe, can do just that.

To make things even easier there are 3 batch files that are also included:

1. install_giveio.bat Install and start the giveio driver.
2. status_giveio.bat Check on the status of the giveio driver.
3. remove_giveio.bat Stop and remove the giveio driver from memory.

These 3 batch files calls the loaddrv program with various options to install, start, stop, and remove the driver.

When you first execute install_giveio.bat, loaddrv.exe and giveio.sys must be in the current directory. When install_giveio.bat is executed it will copy giveio.sys from your current directory to your Windows directory. It will then load the driver from the Windows directory. This means that after the first time install_giveio is executed, you should be able to subsequently execute the batch file from any directory and have it successfully start the driver.

Note that you must have administrator privilege to load the giveio driver.

A.2.4.2 Windows 95/98

On Windows 95 and 98 the giveio.sys driver is not needed.

A.2.5 Documentation

AVRDUDE installs a manual page as well as info, HTML and PDF documentation. The manual page is installed in `/usr/local/man/man1` area, while the HTML and PDF documentation is installed in `/usr/local/share/doc/avrdude` directory. The info manual is installed in `/usr/local/info/avrdude.info`.

Note that these locations can be altered by various configure options such as ‘`--prefix`’ and ‘`--datadir`’.

A.2.6 Credits.

Thanks to:

- Dale Roberts for the giveio driver.
- Paula Tomlinson for the loaddrv sources.
- Chris Liechti <cliechti@gmx.net> for modifying loaddrv to be command line driven and for writing the batch files.

Appendix B Troubleshooting

In general, please report any bugs encountered via <http://savannah.nongnu.org/bugs/?group=avrdude>.

- Problem: I'm using a serial programmer under Windows and get the following error:
`avrdude: serial_open(): can't set attributes for device "com1",`
 Solution: This problem seems to appear with certain versions of Cygwin. Specifying `"/dev/com1"` instead of `"com1"` should help.
- Problem: I'm using Linux and my AVR910 programmer is really slow.
 Solution (short): `setserial port low_latency`
 Solution (long): There are two problems here. First, the system may wait some time before it passes data from the serial port to the program. Under Linux the following command works around this (you may need root privileges for this).
`setserial port low_latency`
 Secondly, the serial interface chip may delay the interrupt for some time. This behaviour can be changed by setting the FIFO-threshold to one. Under Linux this can only be done by changing the kernel source in `drivers/char/serial.c`. Search the file for `UART_FCR_TRIGGER_8` and replace it with `UART_FCR_TRIGGER_1`. Note that overall performance might suffer if there is high throughput on serial lines. Also note that you are modifying the kernel at your own risk.
- Problem: I'm not using Linux and my AVR910 programmer is really slow.
 Solutions: The reasons for this are the same as above. If you know how to work around this on your OS, please let us know.
- Problem: Updating the flash ROM from terminal mode does not work with the JTAG ICEs.
 Solution: None at this time. Currently, the JTAG ICE code cannot write to the flash ROM one byte at a time.
- Problem: Page-mode programming the EEPROM (using the `-U` option) does not erase EEPROM cells before writing, and thus cannot overwrite any previous value `!= 0xff`.
 Solution: None. This is an inherent feature of the way JTAG EEPROM programming works, and is documented that way in the Atmel AVR datasheets. In order to successfully program the EEPROM that way, a prior chip erase (with the `EESAVE` fuse unprogrammed) is required. This also applies to the STK500 and STK600 in high-voltage programming mode.
- Problem: How do I turn off the *DWEN* fuse?
 Solution: If the *DWEN* (debugWire enable) fuse is activated, the */RESET* pin is not functional anymore, so normal ISP communication cannot be established. There are two options to deactivate that fuse again: high-voltage programming, or getting the JTAG ICE mkII talk debugWire, and prepare the target AVR to accept normal ISP communication again.

The first option requires a programmer that is capable of high-voltage programming (either serial or parallel, depending on the AVR device), for example the STK500. In high-voltage programming mode, the */RESET* pin is activated initially using a

12 V pulse (thus the name *high voltage*), so the target AVR can subsequently be reprogrammed, and the *DWEN* fuse can be cleared. Typically, this operation cannot be performed while the AVR is located in the target circuit though.

The second option requires a JTAG ICE mkII that can talk the debugWire protocol. The ICE needs to be connected to the target using the JTAG-to-ISP adapter, so the JTAG ICE mkII can be used as a debugWire initiator as well as an ISP programmer. AVRDUDE will then be activated using the *jtag2isp* programmer type. The initial ISP communication attempt will fail, but AVRDUDE then tries to initiate a debugWire reset. When successful, this will leave the target AVR in a state where it can accept standard ISP communication. The ICE is then signed off (which will make it signing off from the USB as well), so AVRDUDE has to be called again afterwards. This time, standard ISP communication can work, so the *DWEN* fuse can be cleared.

The pin mapping for the JTAG-to-ISP adapter is:

| JTAG pin | ISP pin |
|----------|---------|
| 1 | 3 |
| 2 | 6 |
| 3 | 1 |
| 4 | 2 |
| 6 | 5 |
| 9 | 4 |

- Problem: Multiple USBasp or USBtinyISP programmers connected simultaneously are not found.

Solution: none at this time. The simplicity of these programmers doesn't offer a method to distinguish multiple programmers that are connected simultaneously, so effectively only one of them is supported.

- Problem: I cannot do . . . when the target is in debugWire mode.

Solution: debugWire mode imposes several limitations.

The debugWire protocol is Atmel's proprietary one-wire (plus ground) protocol to allow an in-circuit emulation of the smaller AVR devices, using the */RESET* line. DebugWire mode is initiated by activating the *DWEN* fuse, and then power-cycling the target. While this mode is mainly intended for debugging/emulation, it also offers limited programming capabilities. Effectively, the only memory areas that can be read or programmed in this mode are flash ROM and EEPROM. It is also possible to read out the signature. All other memory areas cannot be accessed. There is no *chip erase* functionality in debugWire mode; instead, while reprogramming the flash ROM, each flash ROM page is erased right before updating it. This is done transparently by the JTAG ICE mkII (or AVR Dragon). The only way back from debugWire mode is to initiate a special sequence of commands to the JTAG ICE mkII (or AVR Dragon), so the debugWire mode will be temporarily disabled, and the target can be accessed using normal ISP programming. This sequence is automatically initiated by using the JTAG ICE mkII or AVR Dragon in ISP mode, when they detect that ISP mode cannot be entered.

- Problem: I want to use my JTAG ICE mkII or AVR Dragon to program an Xmega device through PDI. The documentation tells me to use the *XMEGA PDI adapter for JTAGICE mkII* that is supposed to ship with the kit, yet I don't have it.

Solution: Use the following pin mapping:

| JTAGICE mkII probe | Target pins | Squid cab- le colors | PDI header |
|-------------------------------|------------------------|---------------------------------|-----------------------|
| 1 (TCK) | | Black | |
| 2 (GND) | GND | White | 6 |
| 3 (TDO) | | Grey | |
| 4 (VTref) | VTref | Purple | 2 |
| 5 (TMS) | | Blue | |
| 6 (nSRST) | PDI_CLK | Green | 5 |
| 7 (N.C.) | | Yellow | |
| 8 (nTRST) | | Orange | |
| 9 (TDI) | PDI_DATA | Red | 1 |
| 10 (GND) | | Brown | |

- Problem: I want to use my AVRISP mkII to program an ATtiny4/5/9/10 device through TPI. How to connect the pins?

Solution: Use the following pin mapping:

| AVRISP connector | Target pins | ATtiny pin # |
|-----------------------------|------------------------|-------------------------|
| 1 (MISO) | TPIDATA | 1 |
| 2 (VTref) | Vcc | 5 |
| 3 (SCK) | TPICLK | 3 |
| 4 (MOSI) | | |
| 5 (RESET) | /RESET | 6 |
| 6 (GND) | GND | 2 |

- Problem: My ATtiny4/5/9/10 reads out fine, but any attempt to program it (through TPI) fails. Instead, the memory retains the old contents.

Solution: Mind the limited programming supply voltage range of these devices.

In-circuit programming through TPI is only guaranteed by the datasheet at $V_{cc} = 5$ V.

- Problem: My ATxmega...A1/A2/A3 cannot be programmed through PDI with my AVR Dragon. Programming through a JTAG ICE mkII works though, as does programming through JTAG.

Solution: None by this time (2010 Q1).

It is said that the AVR Dragon can only program devices from the A4 Xmega sub-family.